



Recommended maintenance for your vehicle

2000 Ford F-250

Driving Condition: Normal Condition
Fuel: Diesel

Mileage	15k	30k	45k	60k	75k	90k	100k	105k	120k	135k	150k
Inspect engine cooling system and hoses	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓
Inspect brake pads/shoes/rotors/drums, brake lines and hoses, and parking brake system	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓
Check and lubricate clutch release lever	✓		✓		✓			✓		✓	
Add 8 to 10 oz of VC-8 coolant additive to green engine coolant		✓	✓	✓	✓	✓		✓	✓	✓	
Replace fuel filter	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓
Inspect wheel ends for end play and noise	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓
Inspect and lubricate steering linkage, ball joints, suspension and, if equipped, half shafts drive shaft and u-joints	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓
Replace engine air filter		✓		✓		✓			✓		✓
Inspect complete exhaust system and heat shields		✓		✓		✓			✓		✓
Change automatic transmission fluid		✓		✓		✓			✓		
Change green engine coolant			✓		✓			✓		✓	
Change manual transmission fluid				✓					✓		
Lubricate 4x4 front hub needle bearings				✓					✓		
Lubricate 4x2 front wheel bearings, replace grease seals, and adjust bearings				✓					✓		
Inspect accessory drive belt(s)							✓				
Change front axle lubricant											✓
Change transfer case fluid											✓
Change automatic transmission/transaxle fluid and filter											✓
Replace front 4x2 wheel bearings and grease seals, lubricate and adjust bearings											✓
Replace accessory drive belts (if not replaced within last 100,000 miles)											



**EVERY
5,000
MILES**

- ☑ Check engine air filter restriction gauge, replace filter as required
- ☑ Perform multi-point inspection
- ☑ Rotate tires for optimal tire life
- ☑ Change engine oil and replace oil filter